

Echoplex *Digital Pro* **Gibson**

Input **Output** **Feedback** **Mix** **LOOP** **LOOPTIME** **MULTIPLE**


Parameters	Record	Overdub	Multiply	Ins/Rev	Mute	Undo	NextLoop
Loops	MoreLoops	AutoRecord	LoopCopy	SwitchQuant	LoopTrig #	Velocity	SamplerStyle
MIDI	Channel	ControlSource	Source #	VolumeCont	FeedBkCont	Dump	Load
Switches	RecordMode	OverdubMode	RoundMode	InsertMode	MuteMode	Overflow	Reserved
Timing	Loop/Delay	Quantize	8ths/Cycle	Sync	Threshold	Reverse	Startpoint

POWER


Echoplex rear panel graphic rev C

100-240 VAC
50-60 Hz ■ 15 Watts

Voltage
Selector



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



Attention: RISQUE DE CHOC ELECTRIQUE
NE PAS OUVRIE

No user serviceable parts inside.
Refer servicing to qualified personnel.
Il ne se trouve à l'intérieur aucune pièce pouvant être réparée par l'utilisateur. S'adresser à un réparateur compétent.

Gibson

Made in the UK

sync

Brother Beat

MIDI

In Out Thru

Foot Switches

FootPedal Overdub Feedback

Audio

Output Input